

Exploded diagram and spare parts list (DB167

		`	
D 1	67	1	
DT	υ/	,	

Rev.	1
110 .	.

		REV.1		
Machine	Explode	Code	Description	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	1	Â	Griddle Plate Assembly	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	2	AB077	Heating Element	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	3	Â	Temperature Sensor Fixing	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	4	AB078	Mica Plate	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	5	AB079	Insulation Panel	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	6	AJ153	Power Cord	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	7	Å	Bushing	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	8	N125	Thermostat	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	9	N152	Feet	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	10	AK361	Кпоb	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	11	AA031	Indicator Light	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	12	AJ760	Tray	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	13	AH040	Switch	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	14	N126	Breaker	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	15	AG597	Stick	
Buffalo Steel Plate Countertop Griddle Large (738x330mm) - 2.9kW	16	AG599	Plastic Cover	