















Machine	Explode	Code	Description
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	1		Espr-2 Body
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	2		Front Panel-2
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	3		Inner Assy-2
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	4		Heat Shield Assy-2
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	5		Finger Bar-2
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	6		Back Panel-2
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	7		Fixed Plate-2
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	8	AK221	Power Cord
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	9		Power Cord Buckle
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	10		Wire Bushing
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	11	AK222	Fuse Holder
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	12		Fuse
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	13	AK223	Thermostat
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	14	AK225	Indicator
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	15	AK227	Timer
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	16	AK228	Timer Knob
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	17		Base Plate
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	18	AK235	Crumb Tray
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	19		Screw/Nut
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	20	AK241	Rubber Feet (set 4)
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	21	AK230	Nut
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	22		Spring
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	23		Ejectorbar
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	24		Sphere Knob
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	25		Guard Wire
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	26	AK231	End Element 310W
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	27	AK232	Middle Element 400W
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	28	AK233	Element Link
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	29		Left Casting Traffic Red
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	30		Right Casting Traffic Red
DR065 - Rowlett Esprit 2 Slot Toaster Traffic Red	31		AI Sticker